

ThinkVacuums

"Your Vacuum Headquarters" Over 50 Years Experience

[Home](#)















Do It Yourself Helpful Tips For Installing A Central Vacuum System









Need Technical Support?

Call Us
1.800.322.2965



❖ 2016 All Rights Reserved. Any use of the layout, design, structure or imagery on this page without permission from Thinkvacuums.com is prohibited.

<p>Correct</p>  <p>Use a miter box or tube cutter. Debur tubing after cutting.</p>	<p>Wrong</p>  <p>Cutting like this does not give square ends or clean cuts.</p>
<p>Correct</p>  <p>Apply adhesive on outside of tubing end. When inserting into elbow or fitting, twist to distribute glue</p>	<p>Wrong</p>  <p>Applying adhesive to inside of fitting may cause clogs because adhesive accumulates inside tube.</p>
<p>Correct</p>  <p>Assemble TY's to provide smooth air flow to power unit.</p>	<p>Wrong</p>  <p>Improper installation causes poor air flow.</p>
<p>Correct</p>  <p>Assemble TY's so that dirt enters trunk line from the side or top</p>	<p>Wrong</p>  <p>Gravity causes dirt to fall down the wrong tube.</p>
<p>Correct</p>  <p>Air flow does not conflict.</p>	<p>Wrong</p>  <p>Causes a conflict in air flow.</p>
<p>Correct</p>  <p>Leave slack in the wires at the connection and clip or tape in place.</p>	<p>Wrong</p>  <p>May cause connections to pull apart.</p>
<p>Correct</p>  <p>These will provide good air flow.</p>	<p>Wrong</p>  <p>This causes poor air flow.</p>

 <p>Keeps beams and rafters strong.</p> <p>© Thinkvacuums.com</p>	 <p>Drilling off center weakens beams and rafters.</p> <p>© Thinkvacuums.com</p>
<p>Correct</p>  <p>Smooth Air Flow</p> <p>CENTRAL VAC ELBOW</p> <p>CENTRAL VAC TUBING</p> <p>Smooth Wall Inside Tubing</p> <p>© Thinkvacuums.com</p>	<p>Wrong</p>  <p>PLUMBING ELBOW</p> <p>SCHEDULE 40 (PLUMBING)</p> <p>Never use plumbing pipe and fittings. Inside wall surfaces are rough and elbows are too tight to provide efficient air flow.</p> <p>© Thinkvacuums.com</p>
<p>Correct</p>  <p>90 Degree Long elbows provide efficient air flow.</p> <p>© Thinkvacuums.com</p>	<p>Wrong</p>  <p>90 Degree Short elbows are NOT interchangeable with 90 degree long elbows. Use 90 degree short elbows only with inlet valves.</p> <p>© Thinkvacuums.com</p>
<p>Correct</p>  <p>Thoughtfully planned.</p> <p>© Thinkvacuums.com</p>	<p>Wrong</p>  <p>Unplanned.</p> <p>© Thinkvacuums.com</p>

The image and text content contained on this page originally obtained from VDTA (Vacuums Dealers Trade Association) - March 2002 Publication.